



1	floppy-drive connector (DSKT)	12	CD drive audio cable connector (CD_IN)
2	CD/DVD drive connector (IDE2)	13	front-panel audio cable connector (FRONTAUDIO)
3	battery socket (BATTERY)	14	power connector (12VPOWER)
4	front-panel connector (FRONTANEL)	15	serial port connector (SER2) for optional serial port cards
5	IDE hard-drive connector (IDE1)	16	microprocessor and heat sink connector (CPU)
6	serial ATA hard-drive connector (SATA2)	17	microprocessor fan connector (FAN)
7	serial ATA hard-drive connector (SATA1)	18	memory module connectors (DIMMs 1, 3, 2, and 4)
8	internal speaker (SPEAKER)	19	power connector (POWER)
9	standby power light (AUX_PWR)	20	RTC reset jumper (RTCST)
10	AGP card connector (AGP)	21	password jumper (PSWD)
11	PCI connectors (PCI 1, 2, 3, and 4))		